# How to Export a TPT file from TPT Designer to Home Control Plus and or Home Control Pocket Plus

-Download Home Control Plus or Home Control Pocket Plus from iTunes Directly to your Apple Device

# Creating a folder to Export your TPT file

- Right Click on desktop and create a new folder




# Creating a folder to Export your TPT file


- Right Click on desktop and create a new folder
  Name this folder according to how you want it labeled in the Home Control Application




- Open Touchscreen Designer, from the Design tab select Export To..




- Open Touchscreen Designer, from the Design tab select Export To..
- Click Export Files



- Open Touchscreen Designer, from the Design tab select Export To..
- Click Export Files
- Find the file you previously created and Click Open




- Open Touchscreen Designer, from the Design tab select Export To..
- Click Export Files
- Find the file you previously created and Click Open
- Click Save



## Zipping the TPT file for iTunes File Sharing

- Right Click on the File with the TPT Design, Select Send To, then Compressed (zipped) Folder



## Zipping the TPT file for iTunes File Sharing

- Right Click on the File with the TPT Design, Select Send To, then Compressed (zipped) Folder Compressed (zipped) Folder should show on your Desktop



- Plug the Apple Device into your Computer "There is no need to Sync the Device" Select your Device


\*\*Note Transferring files into iTunes File sharing does not require syncing the device, it is possible to transfer the TPT file from a computer that is not associated with the device.




- Plug the Apple Device into your Computer "There is no need to Sync the Device"
- Select your Device
- Select the Apps Tab




- Plug the Apple Device into your Computer "There is no need to Sync the Device"
- Select your Device
- Select the Apps Tab
- Scroll to the bottom of the Page



- Plug the Apple Device into your Computer "There is no need to Sync the Device"
- Select your Device
- Select the Apps Tab
- Scroll to the bottom of the Page
- Select HC Plus and Click Add



- Plug the Apple Device into your Computer "There is no need to Sync the Device"
- Select your Device
- Select the Apps Tab
- Scroll to the bottom of the Page
- Select HC Plus and Click Add
- Select the Zipped TPT file and Click Open



- Plug the Apple Device into your Computer "There is no need to Sync the Device"
- Select your Device
- Select the Apps Tab
- Scroll to the bottom of the Page
- Select HC Plus and Click Add
- Select the Zipped TPT file and Click Open
- The File is now on the Device and ready to Run

